



ENDF/B-VII HE-4
Principal cross sections




ENDF/B-VII HE-4
Heating




ENDF/B-VII HE-4


Damage




ENDF/B-VII HE-4
Principal cross sections



ENDF/B-VII HE-4
Heating



ENDF/B-VII HE-4
Damage



ENDF/B-VII HE-4
angular distribution for elastic

